

INSTRUCTIONS D'UTILISATION

Lisez attentivement ces instructions avant d'utiliser l'assiette, le bol et les couverts et conservez-les pour pouvoir vous y référer ultérieurement.

Age d'utilisation : 6 mois à 6 ans.

Utilisation du produit

-Ne pas utiliser au four à micro-ondes pour réchauffer les aliments.

-Ne pas utiliser au four traditionnel

-Température maximale tolérée : 70°C

-Avant la première utilisation, nettoyer l'assiette, le bol et les couverts.

-Vérifier l'assiette, le bol et les couverts avant chaque utilisation. Si vous remarquez quelque dégradation que ce soit, arrêter de les utiliser immédiatement.

Nettoyage:

-Nettoyer au lave-vaisselle.

Rangement :

-Ranger l'assiette, le bol et les couverts à l'abri de sources de chaleur ou de la lumière directe du soleil.

Pour la sécurité de l'enfant et par mesure d'hygiène : AVERTISSEMENT !

-Ces produits doivent toujours être utilisés sous la surveillance d'un adulte.

-Avant chaque utilisation, examiner les produits. Les jeter dès les premiers signes de détérioration ou fragilité.

-Toujours vérifier la température de l'aliment avant de donner à manger à l'enfant.

-Le chauffage au four micro-ondes peut engendrer localement de hautes températures. Ne pas l'utiliser

-Toujours remuer l'aliment une fois chauffé pour garantir une répartition uniforme de la chaleur.

Norme en vigueur: EN 14372

INSTRUCTIONS

Read these instructions carefully before using the plate, bowl and cutlery and keep them for future reference.

Age of use: 6 months to 6 years.

Used of the product:

-Can not be used in the microwave to heat food.

-Do not use in the oven

-Maximum temperature tolerated: 70°C (158F).

-Before first use, clean the plate, bowl and cutlery.

-Please check the plate, bowl and cutlery before each use. If you notice any degradation, stop using this plate, bowl and cutlery immediately.

Cleaning:

- Clean in the dishwasher.

Storage:

-Keep the plate, bowl and cutlery away from sources of heat or direct sunlight.

For your child's safety and health measure: WARNING !

- Always use these products with adult supervision.

-Before each use, inspect the products. Throw away at the first sign of damage or weakness.

- Always check the temperature of the food before feeding the child.

-Heating in a microwave oven may produced localised high temperatures. Don't use it.

-Always stir food to ensure even heat distribution and test the temperature before serving.

Valid norm: EN 14372